




PDC-35

**PROFESSIONAL MP3/CD PLAYER
USB/SD PLAYER/RECORDER**



USER'S MANUAL

172.824

IMPORTANT SAFETY PRECAUTIONS




This symbol is to alert the user to the presence of uninsulated dangerous voltages inside the product's enclosure that may constitute a risk of electric shock.



This symbol is to alert the user to important operating and maintenance(service) instructions in this manual and literature accompanying the product.

Caution Marking Explanation



WARNING: CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE WILL VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT. ANY CHANGE TO THE EQUIPMENT WILL VOID FCC GRANT.

This equipment has been tested and found to comply with the limits for a Class C digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technical for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR CORDS. IF THIS HAPPENS, BE SURE POWER TO THE ELECTRICAL OUTLET IS TURNED OFF BEFORE YOU TOUCH OR UNPLUG THE APPLIANCE.

Outdoor Use and Wet Location Warning

Note:

1. Important safety instructions shall be provided with each appliance. These safety instructions may be in the form of a separate booklet, separate sheet, or part of the instruction manual.
2. If included in the instruction manual, the safety instructions shall be located before any operating instructions.
3. These instructions shall be entitled "IMPORTANT SAFETY INSTRUCTIONS"
4. The safety instructions shall include, as applicable to the particular apparatus, the information and warnings listed before. The wording is capable of being supplemented, although not replaced, by drawing or cartoons.
5. The symbol shall be shown adjacent to the text of important safety instructions.

IMPORTANT SAFETY PRECAUTIONS



Safety Instructions



Installation

- * Operate the unit only from a power source as indicated on the unit or in the operating instructions.
- * Overloaded AC outlets and extension cords are dangerous and so are frayed cords and broken plugs. Call your service technician for replacement of such cords and plugs.
- * Audio products are provided with ventilation openings to allow heat generated during operation to be released. If these openings are blocked, heat build-up within the set can cause failure which may result in a fire hazard.

Therefore:

1. Never block the ventilation openings of a unit by placing it on a bed, soft rug, etc.
2. Never place a set in a built-in enclosure unless proper ventilation is provided.
3. Never cover the opening with cloth or other material.
4. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

To avoid personal injury:

1. The manufacturer recommends that this unit not be mounted on a wall or ceiling.
2. Carefully follow the operating instructions when making connections.
3. Do not insert tools, hands, or fingers in openings (such as tape slot), especially if the unit is connected to a power source.

WARNING

Do not turn on your stereo system with the volume at maximum.
This will damage your speakers and void your warranty.

Getting your system ready for use

Choose an area away from heat. Allow about three(3) inches between the cabinet back and the wall for proper ventilation. Place your system near an AC outlet supplying common household current (105-120V AC60Hz).

Grounding or polarization

Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

Power cord protection

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Carts and stands

Use only with a cart, stand tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



Water and Moisture

The appliance should not be used near water, for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement or near a swimming pool and the like.

IMPORTANT SAFETY PRECAUTIONS

Cleaning

The appliance should be cleaned only as recommended by the manufacturer.

Non-use periods

Unplug this apparatus during lightning storms or when unused for long periods of time.

Object and liquid entry

Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.

Damage requiring service

The appliance should be serviced by qualified service personnel when:

- A. The power supply cord or the plug has been damaged.
- B. Objects have fallen, or liquid has been spilled into the appliance.
- C. The appliance has been exposed to rain.
- D. The appliance does not appear to operate normally or exhibits a marked change in performance.
- E. The appliance has been dropped, or the enclosure damaged.

Servicing

Do not attempt to service the appliance beyond that which is described in the operating instructions. All other servicing should be referred to qualified service personnel.


Outdoor antenna grounding

If an outside antenna is connected to the receiver, be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges. Section 810 of the National Electrical Code, ANSI/NFPA NO. 70-1984, provides information with regard to proper grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Figure 1.

IMPORTANT SAFEGUARDS

- 1. READ INSTRUCTIONS**-All the safety and operating instructions should be read before the product is operated.
- 2. RETAIN INSTRUCTIONS**-The safety and operating instructions should be retained for future reference.
- 3. HEED WARNING**-All warnings on the appliance and in the operating instructions should be adhered to.
- 4. FOLLOW INSTRUCTIONS**-All operating and use instructions should be followed.

REFERENCE DRAWING FOR FRONT PANEL



IMPORTANT

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CD player Function:

1. EJECT BUTTON

Press to load or eject disk. Each press will open or close the disk tray.

NOTE: Disc holder will not open unless stop or pause button has been pushed first.

2. PLAY/PAUSE BUTTON

Each time you press the PLAY/PAUSE button, the operation changes from play to pause or from pause to play.

3. CUE BUTTON

Pressing the CUE button during play provides a return to the position at which play was started.

4. CD/USB BUTTON

Pressing the CUE button during play provides a return to the position at which play was started.

5. TIME BUTTON

Used this button to choose the time mode: Elapsed time, remaining time or total remaining time.

6. REPEAT BUTTON

Use this button to repeat one track or all the track of the CD

7. RELOOP BUTTON

This button is used to start the last saved loop. To finish the loop, press the reloop button.

8. IN BUTTON

This button sets the beginning of the loop. The Loop indicator on the display flashes.

9. OUT BUTTON

When you press this button, you set the end point of the seamless loop and you start the loop. To finish the loop, press again this button.

10. CONT. / SINGLE BUTTON

Press this button to switch between the SINGLE and CONTINUOUS play mode. The selected mode is indicated on the LCD. In SINGLE mode, after each track, the unit stops the reading. In CONTINUOUS mode, the unit reads all tracks and stops.

11. .PROG AND FOLDER CONVERSION BUTTON

In STOP mode, you can program several tracks (20 tracks max):

Press the STOP button to enter in the stop mode

Press the PROG button to enter in the program mode

Use the skip track buttons to choose the track you want to listen then press the PROG button to enter your choice.

Use one more time the skip track buttons to choose the track you want to listen then press the PROG button to enter your choice.

Repeat the operation to select all the track you want to listen

Press the play/pause button to start the playback

12. +10 BUTTON

Use this button to jump of 10 tracks in one press.

13. SKIP I<< BUTTON

Use this switch to restart the track or to select the last track.

14. SKIP >>| BUTTON

Use this button to select the next track.

15. FOLDER BUTTON

Allows you to navigate through folders similarly in either USB or CD mode.

16. BUTTON

For selecting random play. With the function activated, the LCD will light up.

17. PITCH BEND-BUTTON

The pitch will drop while the  button is pressed and return to the original pitch when it is released.

18. PITCH BEND+BUTTON

The pitch will automatically rise when the + button is pressed and return to the original pitch when it is released.

19. USB PORT

Support USB playing and you may also connect the computer with the USB cable but only when enter into USB work mode.

20. DISPLAY

21. DISC-TRAY

To enter the disc, please refer to the explanations under 6.2 CD-tray.

22. DELETE BUTTON

Delete songs on the SD or USB track.

23. SD CARD SLOT

Slot for inserting SD card. The contacts of the card must point downwards. Unit cannot read cards with a capacity of more than 4GB. The unit is not compatible to SDHC cards and only.

24. FOLDER

Allows you to navigate through folders or tracks similarly in either USB or SD mode.

25. USB PORT

ALLOWS THE CONNECTION OF ANY USB MEMORY STICK.

24. FOLDER

Allows you to navigate through folders or tracks similarly in either USB or SD mode.

26. +10 BUTTON

Use this button to jump of 10 tracks in one press.

27. DISPLAY

28. HEADPHONE VOLUME

Adjust the headset volume

29. REPEAT BUTTON

USE THIS BUTTON TO REPEAT ONE TRACK OR ALL THE TRACK OF THE CD

30. CONT. / SINGLE BUTTON

Press this button to switch between the SINGLE and CONTINUOUS play mode. The selected mode is indicated on the LCD. In SINGLE mode, after each track, the unit stops the reading. In CONTINUOUS mode, the unit reads all tracks and stops.

31. SD/USB BUTTON

Press this button to choose SD or USB mode while USB connect and the SD in the tray.

32. SKIP |<< BUTTON

Use this switch to restart the track or to select the last track.

33. SKIP >>| BUTTON

Use this button to select the next track.

34. RECORD BUTTON

Enter the recording mode.

35. STOP BUTTON

Pressing the CUE button during play provides a return to the position at which play was started.

36. PLAY BUTTON

Each time you press the PLAY/PAUSE button, the operation changes from play to pause or from pause to play.


37. RECORD VOLUME

Used to adjust the level of volume which be recording.

38. HEADPHONESINPUTS

3.5 MM JACKS HEADPHONE FOR CONNECTING STEREO HEADPHONES

REFERENCE DRAWING FOR BACK PANEL

**39. AC CORD**

Use this cable to connect the AC mains power to the unit.

40. POWER BUTTON

Press the power switch to turn the unit on. To switch power off press the power switch again.

41. LINE OUT (B)

The audio for the left USB player is an output for these jacks

42. LINE IN

The audio for each SD/USB player is an input for these jacks

43. LINE OUT

The audio for each SD/USB player is an input for these jacks

44. LINE OUT (A)

The audio for right SD player is an input for these jacks

This button sets the beginning of the loop. The Loop indicator on the display flashes.

WARRANTY CONDITIONS

PDC-35 equipment is covered by a 1-year warranty on parts and labour except for faders(90 days).The following rules apply from the day the equipment leaves the factory:

The date on the invoice is considered to be the date the warranty begins.

Only companies approved by **PDC-35** are allowed to work on the equipment.Warranty becomes void when other service technicians open the equipment.

During warranty period,defective equipment must be sent by pre-paid mail in the original box.

PDC-35 will return the goods by pre-paid mail during the first year of warranty;thereafter the mailing cost is to be paid by the recipient.

Potentiometers have a limited lifetime and are not covered by the manufacturer for more than normal use. For all service enquiries,refer to your local distributor,as he is best able to help you.



tronios
Sound & Light

CE Declaration of Conformity

Importer: TRONIOS BV
Bedrijvenpark Twente 415
7602 KM - ALMELO
Tel : 031546589299
Fax : 0031546589298
The Netherlands

Product number: 172.724

Product Description: **Power Dynamics PDC-35 Digital Recorder
CD/USB/SDMP3**

Regulatory Requirement: EN 55013
EN 55020
EN 61000-3-2/3-3
EN 60065

The product met the requirements stated in the above mentioned Declaration(s).
This certificate does not cover the aspects that may be relevant such as performance and fitness for purpose.

ALMELO,
19-07-2010

Signature